


comfee'

Dishwasher

!InstructionManual



Free 3 months extension of the original limited warranty period!* Simply text a picture of your proof of purchase to:

1-844-224-1614

*The warranty extension is for the three months immediately following the completion of the product's original warranty period.

Models:
CDC22P2AWW
CDC22P1ABB



Read this Manual

Dear Customer,

- Please carefully read this manual before using the dishwasher
This will help you use and maintain the dishwasher properly
- Keep it to refer to at a later date
- Pass it on to any subsequent owner of the appliance

This manual contains sections of Safety Instructions
Operating Instructions Installation Instructions and
Troubleshooting Tips etc



Before Calling for Service

- Review the Troubleshooting Tips section to solve some
common problems by yourself
- If you can not resolve the troubles by yourself
please ask for the help of professional technicians



NOTE:

The manufacturer following a policy of constant
development and updating of the product may
make modifications without giving prior notice

1) Safety Information.....	1
2) Operating Instructions.....	3
Control Panel	3
Dishwasher Features	3
3) Before First Use.....	3
A Fill the Rinse Aid Dispenser	3
B Function of Detergent	
4) Loading the Dishwasher Basket.....	%
Attention before or after loading the Dishwasher Baskets	6
Loading the Basket	7
Cutlery Basket	8
5) Starting a Washing Program.....	9
Wash Cycle Table	9
Turning on the Appliance	9
Change the Programme	10
At the End of the Wash Cycle	10
6) Maintenance and Cleaning	11
Filtering System	11
Caring for the Dishwasher	12
7) Installation Instruction	13
Positioning the Appliance	1
About Power Connection	1
Water Connection	15
Start of dishwasher	15
8) Troubleshooting Tips	1-
Before calling for service	17
Error codes	18
Technical information	19
9) Warranty	20

1 !IMPORTANT SAFETY !INFORMATION READ ALL !INSTRUCTIONS BEFORE USING

⚠ WARNING! When using your dishwasher follow the precautions listed below:



GROUNDING !NSTRUCTIONS

- This appliance must be grounded. In the event of a malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance of electric current. This appliance is equipped with a cord having an equipment-grounding conductor and a grounding plug.
- The plug must be plugged into an appropriate outlet that is installed and grounded in accordance with all local codes and ordinances.

⚠ WARNING!

- Improper connection of the equipment-grounding conductor can result in a risk of electric shock.
- Check with a qualified electrician or service representative if you are in doubt whether the appliance is properly grounded. Do not modify the plug provided with the appliance; if it is not fit for the outlet, have a proper outlet installed by a qualified electrician.



WARNING! PROPER USE

- Do not abuse: sit on or stand on the door or dish rack of the dishwasher.
- Do not touch the heating element during or immediately after use. (This instruction is only applicable to machines with a visual heating element.)
- Do not operate your dishwasher unless all enclosure panels are properly in place. Open the door very carefully if the dishwasher is operating; there is a risk of water squirting out.
- Do not place any heavy objects or stand on the door when it is open. The appliance could tip forward.
- When loading items to be washed:
 - 1) Locate sharp items so that they are not likely to damage the door seal;
 - 2) Warning: Knives and other utensils with sharp points must be loaded in the basket with their points down or placed in a horizontal position.
- When using your dishwasher, you should prevent plastic items from coming into contact with the heating element. (This instruction is only applicable to machines with a visual heating element.)
- Check that the detergent receptacle is empty after completion of the wash cycle.
- Do not wash plastic items unless they are marked dishwasher safe or the equivalent. For plastic items not so marked, check the manufacturer's recommendations.
- Use only detergent and rinse additives designed for an automatic dishwasher.
- Never use soap, laundry detergent, or hand washing detergent in your dishwasher. Keep these products out of the reach of children.
- Keep children away from detergent and rinse aid. Keep children away from the open door of the dishwasher; there could still be some detergent left inside.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Dishwasher detergents are strongly alkaline; they can be extremely dangerous if swallowed. Avoid contact with skin and eyes and keep children away from the dishwasher when the door is open.
- The door should not be left in the open position since this could present a tripping hazard.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Remove the door to the washing compartment when removing an old dishwasher from service or discarding it.
- Please dispose of packing materials properly.
- Use the dishwasher only for its intended function.
- During installation, the power supply must not be excessively or dangerously bent or flattened. Do not tamper with controls.
- The appliance is to be connected to the water mains using new hose sets and that old hose-sets should not be reused.
- The maximum number of place settings to be washed is 6.
- The maximum permissible inlet water pressure is 1Mpa.
- The minimum permissible inlet water pressure is 0.0 Mpa.

⚠ Attention:


The installation of the pipes and electrical equipments should be done by professionals.

**READ AND FOLLOW THIS SAFETY !INFORMATION CAREFULLY
SAVE THESE !INSTRUCTIONS**

2 Operation Instruction



! IMPORTANT To get the best performance from your dishwasher, read all operating instructions before using it for the first time.

Control Panel



- | | |
|---|--|
| 1 Power Button: To turn on/off the power supply | 8 Extra Cleaning Indicator; |
| 2 Child lock function: Press Child button to lock the program; | 9 Child Lock Indicator; |
| 3 Delay Button : To press the button to delay | 10 Express Indicator; |
| 4 Program Selector: Press the button to select wash cycles | 11 Water Faucet Indicator; |
| 5 F unction Selector: To select Extra drying Extra cleaning or Express | 12 Program Indicator Light |
| 6 Start/Pause Button: Press this button to start or pause the dishwasher | 13 Extra Drying Indicators: To show Extra drying function |
| 7 Display Screen: To show remaining time and the state (running state delay time etc) | 14 Rinse Aid Warning Light : To be on when the rinse aid dispenser needs to be refilled |
| | 15 Program Ending Indicator |

Dishwasher Features



- | | | | | |
|--------------------|------------------------------|------------------------------|-------------------------------|-------------------------------|
| 1 Cup Shelf | 3 Detergent Dispenser | 4 Cutlery Basket | 7 Spray Arms | 9 Drain Pipe Connector |
| 2 Basket | 5 Filter Assembly | 6 Rinse Aid Dispenser | 8 Inlet Pipe Connector | |

A Fill the Rinse Aid Dispenser

Rinse Aid Dispenser

The rinse aid is released during the final rinse to prevent water from forming droplets on your dishes. That can leave spots and streaks. It also improves drying by allowing water to slide off the dishes. Your dishwasher is designed to use liquid rinse aids. The rinse aid dispenser is located inside the door next to the detergent dispenser. To fill the dispenser, open the cap and pour the rinse aid into the dispenser until the level indicator turns completely black. The volume of the rinse aid container is about 110ml.

Function of Rinse Aid

Rinse aid is automatically added during the last rinse, ensuring thorough rinsing and spot and streak free drying.

Attention!

Only use branded rinse aid for dishwasher. Never fill the rinse aid dispenser with any other substances (e.g. Dishwasher cleaning agent, liquid detergent). This would damage the appliance.


When to Refill the Rinse Aid Dispenser

If there is no rinse-aid warning light in the control panel, you can judge the amount of rinse-aid by the color of the optical level indicator "C" located next to the cap. When the rinse-aid container is full, the whole indicator will be dark. As the rinse-aid diminishes, the size of the dark dot decreases. You should never let the rinse aid get below 1/2 full.

As the rinse aid diminishes, the size of the black dot on the rinse aid level indicator changes, as illustrated below:

- Full
- ◐ 3/4 full
- ◑ 1/2 full
- ◒ 1/4 full - Should refill to eliminate spotting
- Empty


C (Rinse-Aid indicator)



- 1 To open the dispenser, turn the cap to the "open" (left) arrow and lift it out.
- 2 Pour the rinse aid into the dispenser, being careful not to overfill.
- 3 Replace the cap by inserting it aligned with "open" arrow and turning it to the closed (right) arrow.

NOTE: Clean up any rinse aid spilled during filling with an absorbent cloth to avoid excessive foaming during the next wash. Don't forget to replace the cap before you close dishwasher door.

1 2usting 3inse 1 i "ispenser



The rinse aid dispenser has four settings. The recommended setting is on "3". If the dishes still are not drying properly or are spotted, adjust the dial to the next higher number on "4".



NOTE

Increase the dose if there are drops of water or lime spots on the dishes after washing. Reduce it if there are sticky whitish stains on your dishes or a bluish film on glassware or knife blades.

B Function of Detergent

Proper Use of Detergent

Detergents with its chemical ingredients are necessary to remove dirt, crush dirt and transport it out of the dishwasher. Use only detergent specifically made for use in dishwashers. Keep your detergent fresh and dry. Don't put powder detergent into the dispenser until you're ready to wash dishes.

Detergents

There are 3 sorts of detergents:

- 1 With phosphate and with chlorine
- 2 With phosphate and without chlorine
- 3 Without phosphate and without chloride

Normally, new pulverised detergent is without phosphate. The water softener function of phosphate is not given. In this case, we recommend to fill salt in the salt container even when the hardness of water is only 6 °dH. If detergents without phosphate were used in case of hard water, often white spots appear at dishes and glasses. In this case, please add more detergent to reach better results. Detergents without chlorine do only bleach a little. Strong and coloured spots will not be removed completely. In this case, please choose a program with higher Temperature.

Concentrated Detergent

Based on their chemical composition, dishwashers can be split in two basic types:

- conventional alkaline detergents with caustic components
- low alkaline concentrated detergents with natural enzymes

The use of "normal" washing program in conjunction with concentrated detergents reduces pollution and is good for your dishes; these wash programs are specially matched to the dirt-dissolving properties of the enzymes of the concentrated detergent. For this reason, "normal" wash program in which concentrated detergents are used can achieve the same results that can otherwise only be achieved using "heavy" program.


Detergent Tablets

Detergent tablets of different brands dissolve at different speeds. For this reason, some detergent tablets cannot dissolve and develop their full cleaning power during short program. Therefore, please use long program when using detergent tablets to ensure the complete removal of detergent residuals.

Detergent Dispenser

The dispenser must be refilled before the start of each wash cycle following the instructions provided in the Wash Cycle Table. Your dishwasher uses less detergent and rinse aid than conventional dishwashers. Generally, only one tablespoon of detergent is needed for a normal wash load. Also, more heavily soiled items need more detergent. Always add the detergent just before starting the dishwasher; otherwise, it could get damp and will not dissolve properly.

Amount of Detergent to Use



NOTE

- If the lid is closed: press release button. The lid springs open.
- Always add the detergent just before starting each wash cycle.
- Only use branded detergent aid for dishwasher.

WARNING!

Dishwasher detergent is corrosive! Take care to keep it out of reach of children.

Fill in detergent

Fill the detergent dispenser with detergent. The marking indicates the dosing levels as illustrated on right:


A Capacity-15g

B Capacity-25g

Please observe the manufacturer's dosing and storage Recommendations as stated on the detergent packaging.

Close the lid and press until it locks in place.

If the dishes are heavily soiled, place an additional detergent dose in the pre-wash detergent chamber. This detergent will take effect during the pre-wash phase.



NOTE

- You find information about the amount of detergent for the single programme on the last page.
- Please be aware that according to the level of soiling and the specific hardness of water, differences are possible.
- Please observe the manufacturer's recommendations on the detergent packaging.

Loading the Dishwasher Baskets

Recommendation

- Consider buying utensils which are identified as dishwasher-proof
- Use a mild detergent that is described as specially for dishware !f necessary seek further information from detergent manufacturers
- For particular items like glassware select a program with as a low temperature
- To prevent damage do not take glass and cutlery out of the dishwasher immediately after the program has ended

Items Not Recommended For The Dishwasher

Are not suitable

- Cutlery with wooden horn china or mother-of-pearl handles
- Plastic items that are not heat resistant
- Older cutlery with glued parts that is not temperature resistant
- Bonded cutlery items or dishes
- Pewter or cooper items
- crystal glass
- Steel items subject to rusting
- Wooden platters
- Items made from synthetic fibres

Are of limited suitability

- Some types of glasses can become dull after a large number of washes
- Silver and aluminium parts have a tendency to discolour during washing
- Glazed patterns may fade if machine washed frequently

Attention Before or After Loading The Dishwasher Baskets

(For best performance of the dishwasher follow these loading guidelines
Features and appearance of baskets and cutlery baskets may vary from your model)

Scrape off any large amounts of leftover food Soften remnants of burnt food in pans

It is not necessary to rinse the dishes under running water

Place objects in the dishwasher in following way:

- 1 Items such as cups glasses pots/pans etc are face down
 - 2 Curved items or those with recesses should be loaded at a slant so that water can run off
 - 3 All utensils are stacked securely and can not tip over
- All utensils are placed in the way that the spray arms can rotated freely during washing






NOTE: Very small items should not be washed in the dishwasher as they could easily fall out of the basket

- Load hollow items such as cups glasses pans etc With the opening downwards so that water cannot collect in the container or a deep base
- Dishes and cutlery must not lie inside one another or cover each other
- To avoid damage to glasses they must not touch
- Load large items which are most difficult to clean into the basket
- Long bladed knives stored in an upright position are a potential hazard!
- Long and/or sharp items of cutlery such as carving knives must be positioned horizontally in the basket
- Please do not overload your dishwasher This is important for good results and for reasonable energy consumption

Loading the Basket

Position the dishes and cookware so that they will not get moved by the spray of water










Cup Rack Basket

The basket is fitted with plate racks which can be stowed horizontal if required

Cutlery Basket

Cutlery should be placed in the cutlery basket with handles at the bottom. If the rack has side baskets, the spoon should be loaded individually into the appropriate slots, especially long utensils should be placed in the horizontal position at the front of the upper basket as shown.



1	Dinner forks	
2	Salad forks	
3	Knives	
4	Teaspoons	
&	Serving spoons	
%	Serving forks	



⚠ WARNING!

- Do not let any item extend through bottom
- Always load sharp utensils with the sharp point down!

For personal safety and a top quality clean, place the silverware in the basket:

- So they do not nest together
- With handles facing down
- Sharp knives and other potentially dangerous utensils with handles facing up

5 Starting a Washing Program

Wash Cycle Table



NOTE

- (★) Means need to fill rinse into the "rinse#aid" dispenser.
- & \$ ' \$! % (#) # * + , This program is the test cycle, the rinse#aid dispenser setting is recommended to - osition ..

Program	Cycle Selection Information	Description of Cycle	Detergent pre/main	Running time(min)	Energy (Kwh)	Water (l)	Rinse Aid
 Heavy	For the heaviest soiled loads such as pots pans casserole dishes and dishes that have been sitting with dried food on them for a while	Pre-wash Pre-wash(50i) Wash (55i) Wash (50i) Rinse Rinse (68i) Drying)/g	100	0 9	12 5	★
 Normal (*AHAM DW-1-2005)	For normally soiled loads such as pots plates glasses and lightly soiled pans standard daily cycle	Pre-wash Pre-wash Wash (52i) Rinse Rinse (65i) Drying)/g	110	0 36	10 8	★
 BabyCare	For lightly soiled loads such as glasses crystal and fine china	Pre-wash Pre-wash (50i) Wash (55i) Rinse Rinse Rinse(70i) Drying)/g	90	0 51	12 5	★
ECO ECO	For lightly soiled loads such as glasses crystal and fine china	Pre-Wash Pre-Wash(50i) Wash(50i) Rinse Rinse(60i) Drying	18g	75	0 27	10	★
 Glass	For lightly soiled crockery and glass	Pre-Wash Wash(50i) Rinse Rinse(60i) Drying),g	70	0 28	8 5	★
 Speed	A shorter wash for lightly soiled loads that do not need drying	Pre-wash Pre-wash(50i) Wash (50i) Rinse Rinse(55i)	15g	5	0 31	10 5	★
 Rinse	Use for rinsing dishes, glasses and silverware that will not be wash right away	Pre-wash Main-wash	/	2	0 03	3	
 Mini-party	For lightly soiled loads such as glasses crystal and fine china	Main Wash(5i) Rinse Rinse(50i)),g	20	0 18	6 5	

Turning On the Appliance

Starting a wash cycle:

- 1 Draw out the basket(see the section entitled "Loading the Basket ");
- 2 Pour in the detergent (see the section entitled "Detergent and Rinse Aid ");
- 3 Insert the plug into the socket The power supply is 120V/60 Hz;
Make sure that the water supply is turned on to full pressure;
- 5 Close the door and press the on/off button to turn on the power supply;
- 6 Press the program button to select wash program you need
4ea5y678orma,67Ba0y+are679+O67:,ass67Spee 673inse67*ini6party
- 7 Then press the Start/Pause button until dishwasher begins to start



NOTE

When you press the Start/Pause button to pause during washing the display time will stop blinking and the program will pause and remain this cycle till you restart it again

Change the Programs

Premise: You can modify the washing program at the beginning of the cycle. Otherwise, the detergent may have already been released and the appliance may have already drained the wash water. If this is the case, the detergent dispenser must be refilled (see the section entitled "Loading the Detergent").

To change the washing program, press the Start/pause button to pause the machine, then press the program button more than three seconds to set the machine into standby; then you can change the program to the desired cycle setting (See the section entitled "Starting a wash cycle").

The lights show the state of the dishwasher:

- a) All phase lights off-----Stand by
- b) The display no blinking -----Paused
- c) The display blinking -----Running



NOTE: If you open the door when washing, the machine will pause. When you close the door, you need press start/pause button to continue the cycle.

Forgot to Add a Dish?

A forgotten dish can be added any time before the detergent cup opens.

■ Press the start/pause button

■ Open the door a little to stop the washing



■ Add forgotten dishes



■ Close the door

3 After the spray arms stop working, you can open the door completely.



6 Press the start/pause button; the dishwasher will run after 10 seconds.

At the End of the Wash Cycle

When the working cycle has finished, the buzzer of dishwasher will sound for 8 seconds, then stop. Turn off the appliance using the ON/OFF button, shut off the water supply and open the door of the dishwasher. Wait a few minutes before unloading the dishwasher to avoid handling the dishes and utensils while they are still hot and more susceptible to breakage. They will also dry better. Since the appliance is standing by, it will power off automatically after 30 minutes without any operation.

■ Switch Off the Dishwasher

All the phase lights are off; only in this case the program has ended.

- 1 Switch off the dishwasher by pressing the ON/OFF button.
- 2 Turn off the water tap!

■ Open the door carefully

Hot dishes are sensitive to cold shock. The dishes should therefore be allowed to cool down around 15 minutes before removing from the appliance.

Open the dishwasher's door, leave it ajar and wait a few minutes before removing the dishes. In this way they will be cooler and the drying will be improved.

■ Unloading the dishwasher

It is normal that the dishwasher is wet inside.




WARNING!

It is dangerous to open the door when washing because the hot water may scald you.

6 Maintenance and Cleaning

Filtration System

The filter prevent larger remnants of food or other objects from getting inside the pump



The filter system consists of a coarse filter a flat (main filter) and a micro filter (fine filter)

Main filter **A**

Food and soil particles trapped by this filter are pulverized by a special jet on the spray arm and washed down to drain

Fine filter **B**

This filter holds soil and food residue in the sump area and prevents it from being deposited on the dishes during wash cycle

Coarse filter **C**


Larger items such as pieces of bone or glass that could block the drain are trapped in the coarse filter To remove the items caught by the filter gently squeeze the tap on the top of this filter and lift out

Filter Assembly


The filter efficiently removes food particles from the wash water allowing it to be recirculated during the cycle For best performance and results the filter assembly must be regularly cleaned For this reason it is a good idea to remove the larger food particles trapping in the filter after each wash cycle by rinsing the filter and cup under running water To remove the filter assembly pull on the cup handle in the upward direction

⚠ WARNING!


Never run the dishwasher without the filters in place
The dishwasher must never be used without the filters
Improper replacement of the filter may reduce the performance level of the appliance and damage dishes and utensils



Step1\Twist the filter assembly(A B and C) counterclockwise then lift it all up



Step2: Lift B and C up from A;



Complete

⚠ **NOTE:** To re#install the filter system, complete 0tep., 0tep*, and finally, 0tep).

Remarks:

- Inspect the filters for blocking every time the dishwasher has been used
- By unscrewing the coarse filter you can remove the filter system. Remove any food remnants and clean the filters under running water

! NOTE The entire filter assembly should be cleaned once a week

Cleaning The Filter

To clean the coarse filter and the fine filter use a cleaning brush. Reassemble the filter parts as shown in the figures in the last page and reinsert the entire assembly in the dishwasher positioning in its seat and pressing downward

! WARNING!

When cleaning the filters don't knock on them. Otherwise the filters could be contorted which could negatively impact dishwasher performance

Caring for the Dishwasher

The control panel can be cleaned by using a lightly dampened cloth and dry thoroughly

The exterior use a good appliance polish wax

Never use sharp objects, scouring pads or harsh cleaners on any part of the dishwasher

Cleaning The Door



To clean the edge around the door you should use only a soft warm damp cloth. To avoid penetration of water into the door lock and electrical components do not use a spray cleaner of any kind

! WARNING!

Never use a spray cleaner to clean the door panel as it may damage the door lock and electrical components. Abrasive agent or some paper towel should not be used because of the risk of scratching or leaving spots on the stainless steel surface

Protection Against Freezing

Please take frost protection measures on dishwasher in winter. After each wash cycle please operate as follows:

- 1 Cut off electrical power to the dishwasher
- 2 Turn off the water supply and disconnect the water inlet pipe from the water valve
- 3 Drain water from the inlet pipe and water valve (Use a pan to catch the water)
Reconnect the water inlet pipe to the water valve
- 5 Remove the filter at the bottom of the tub and use a sponge to use up water in sump




NOTE *If your dishwasher cannot work because of the ice, please contact professional service persons.*

Cleaning the Spray Arms

The spray arms can be easily removed for periodic cleaning of the nozzles to prevent possible clogging. Wash them under running water and carefully replace them in their seats, checking that their rotary movement is in no way impeded.

Grasp the middle of the spray arm, pull it upwards to remove it. Wash the arms under a jet of running water and return them carefully to their seat. After reassembly, check that the spray arms turn freely. Otherwise, check that they have been installed correctly.



How to Keep Your Dishwasher in Shape

■ After Every Wash

After every wash, turn off the water supply to the appliance and leave the door slightly open so that moisture and odors are not trapped inside.

■ Remove the Plug

Before cleaning or performing maintenance, always remove the plug from the socket.

■ No Solvents or Abrasive Cleaning

To clean the exterior and rubber parts of the dishwasher, do not use solvents or abrasive cleaning products. Only use a cloth with warm soapy water.

To remove spots or stains from the surface of the interior, use a cloth dampened with water with a little vinegar or a cleaning product made specifically for dishwashers.

■ When it is not in need for a long time

It is recommended that you run a wash cycle with the dishwasher empty and then remove the plug from the socket, turn off the water supply and leave the door of the appliance slightly open. This will help the door seals to last longer and prevent odors from forming within the appliance.

■ Moving the Appliance

If the appliance must be moved, try to keep it in the vertical position. If absolutely necessary, it can be positioned on its back.

■ Seals

One of the factors that cause odors to form in the dishwasher is food that remains trapped in the seals. Periodic cleaning with a damp sponge will prevent this from occurring.

7 Installation Instructions

Installation Preparation

The installation position of dishwasher should be near the existing inlet and drain hoses and power cord.

One side of the cabinet sink should be chosen to facilitate the connection of drain hoses of the dishwasher.

Positioning the Appliance

Position the appliance in the desired location. The back should rest against the wall behind it and the sides along the adjacent cabinets or wall. The dishwasher is equipped with water supply and drain hoses that can be positioned to the right or the left to facilitate proper installation.

About Power Connection

⚠ WARNING!

For personal safety:

DO NOT USE AN EXTENSION CORD OR AN ADAPTER PLUG WITH THIS APPLIANCE.
DO NOT UNDER ANY CIRCUMSTANCES CUT OR REMOVE THE EARTHING
CONNECTION FROM THE POWER CORD.

Electrical Requirements

Please look at the rating label to know the rating voltage and connect the dishwasher to the appropriate power supply. Use the required fuse 10 amp time delay fuse or circuit breaker recommended and provide separate circuit serving only this appliance.

Electrical Connection

⚠ Insure proper ground exists before use

Ensure the voltage and frequency of the power being corresponds to those on the rating plate. Only insert the plug into an electrical socket which is earthed properly. If the electrical socket to which the appliance must be connected is not appropriate for the plug, replace the socket rather than using a adaptors or the like as they could cause overheating and burns.



GROUNDING INSTRUCTIONS

This appliance must be earthed. In the event of a malfunction or breakdown, earthing will reduce the risk of electric shock by providing a path of least resistance for the electric current. This appliance is equipped with a cord having an equipment-earthing conductor and an earthing plug. The plug must be plugged into an appropriate outlet that is installed and earthed in accordance with all local standards and requirements.

⚠ WARNING!


Improper connection of the equipment earthing conductor can result in the risk of an electric shock.

Check with a qualified electrician or service representative if you are in doubt whether the appliance is properly earthed.

Do not modify the plug provided with the appliance. If the plug does not fit properly to the outlet, please have a qualified electrician to install a proper outlet.

Water Connection

Back View




Rear of Dishwasher:

1. Drain Port
2. Power Cord
3. Inlet Port

Your dishwasher comes equipped with a 'quick connect' assembly (includes inlet and drain hose). The faucet adapter must be installed on the faucet before you can connect the dishwasher. This adapter is included inside your dishwasher. The faucet adapter is compatible with faucets inclusive of either male (outside) or female (inside) threaded faucet connections

Quick Connect Assembly



Quick Connect Assembly Drain Hose:

1. Drain port connection
2. Quick connect connection

Inlet Hose:

3. Inlet port connection
4. Quick connect connection

Faucet Adapter:

5. Faucet Adapter
6. Faucet washer

Quick Connect:

7. Pressure relief valve
8. Faucet adapter connection
9. Locking collar
10. Inlet hose connection
11. Drain hose connection

⚠ WARNING!

In order to avoid that there is more water staying in the inlet hose please close the faucet after using

1. Screw the faucet adapter onto (or into) the faucet tap. Check for leaks (use Teflon tape to eliminate if necessary).
2. Connect the six-sided connection of the drain hose to the drain port connection on the back of the dishwasher cabinet. Do not over-tighten (to avoid damage to threads).
3. Connect the star-shaped connection of the inlet hose to the inlet port on the back of the dishwasher cabinet. Do not over-tighten (to avoid damage to threads).
4. Connect the circular connection of the drain hose onto the longer (bottom) male connection on the quick connect.
5. Connect the circular connection of the inlet hose onto the shorter (top) male connection on the quick connect.
6. Attach the quick connect onto the faucet adapter by pulling down the outer locking collar on the quick connect while pushing the quick connect upward onto the faucet adapter.
7. When the quick connect snaps onto the faucet adapter, release the locking collar. Verify the connection is secure.
8. Slowly open the hot water line and check for any sign of water leaks at all hose connections. If leaks are located, immediately close the water supply and repair the hose connections.

Important

1. Once you open the water supply line (even if it is closed immediately thereafter) the inlet hose will be pressurized.
2. To relieve water pressure from inside the inlet hose (make sure the water line (faucet) is closed): press and hold the red pressure relief button on the quick connect until the flow of water stops.

' 1 3 8 1 8 :

F11LU39 / O 39LI9; 9 ' 1 / 9 3 (39SSU39, B9FO39 "IS+O889+ / I8: / 49 <UI+=6+O889+ / F3O* / 49 F1U+9/, 'ILL 39SUL/ I8 B1+=6(39SSU39 O;936S(31>. / 49 / 9*(931 / U39 OF I8+O*I8:'1/93 +18 B9;93> 4O/, 18" B1+=6(39SSU39 O;936S(31> +OUL" +1US9 S9;939 BU38S 18"?O3 S+1L"I8:.

" 1 8 : 9 3

"O 8O / L9/ +4IL"398 "IS+O889+ / / 49 "IS4'1S493@ +LOS9 SU(93;ISIO8 OF +4IL"398 IS 1L'1>S I*(O3/18/ 13OU8" 1((LI18+9S.

8O/9A

4ar #ater con itions #i,, a 5erse,y affect t!e #as!ing performance of your is!#as!er. 4ar #ater con itions #i,, a,so contri0ute to BimeB C#!ite fi,m su0stance) eposits an ?or Bsca,ingB on t!e stain,ess stee, surface of t!e is!#as!er tu0 an !eater e,ement,ocate in t!e sump un erneat! t!e remo5a0,e fi,ter screen. /o assist in minimiDing t!ese con itions, it is recommen e to perio ica,,y operate?rinse t!e insi e of t!e is!#as!er Cemty) using 1 cup of #!ite 5inegar at ,east once a #ee\$.

"isconnecting your "is!#as!er

1. Shut off the water supply at the faucet.
2. Disconnect the power supply cord.

Starting the Dishwasher

The following things should be checked before starting the dishwasher.

1. The dishwasher is level and fixed properly.
2. The inlet valve is open.
3. There is a leakage at the connections of the conducts.
4. The wires are tightly connected.
5. The power is switched on.
6. The inlet and drain hoses are knotted.
7. All packing materials and printings should be taken out from the dishwasher.



Attention: \$fter installation, please ma2e sure to 2eep this manual.

The content of this manual is very helpful to the users.

8 Troubleshooting Tips

Before Calling for Service

Review the charts on the following pages may save you from calling for service



	<i>Problem</i>	<i>Possible Causes</i>	<i>What To Do</i>
Technical problems	<i>Dishwasher doesn't start</i>	Fuse blown or the circuit breaker tripped	Replace fuse or reset circuit breaker Remove any other appliances sharing the same circuit with the dishwasher
		Power supply is not turned on	Make sure the dishwasher is turned on and the door is closed securely Make sure the power cord is properly plugged into the wall socket
		Door of dishwasher not properly closed	Closed dishwasher making sure that door latches
	<i>Water not pumped from dishwasher</i>	Kink in drain hose	Check drain hose
		Filter clogged	Check the coarse filter (see section titled "Cleaning The Filter")
General problems		Kitchen sink clogged	Check kitchen sink to make sure it is draining well !If problem is kitchen sink not draining you may need a plumber rather than a serviceman for dishwasher
	<i>Suds in the tub</i>	Improper detergent	Use only the special dishwasher detergent to avoid suds !If this occurs open the dishwasher and let suds evaporate Add 1 gallon of cold water to the tub Close and latch the dishwasher then Start the "soak" wash cycle to drain out the water Repeat if necessary
		Spilled rinse-aid	Always wipe up rinse-aid spills immediately
	<i>Stained tub interior</i>	Detergent with colourant was used	Make sure that the detergent is the one without colourant
	<i>White film on inside surface</i>	Hard water minerals	To clean the interior use a damp sponge with dishwasher detergent and wear rubber gloves Never use any other cleaner than dishwasher detergent for the risk of foaming or suds
Noise	<i>Knocking noise in the wash cabinet</i>	The spray arm is knocking against an item in a basket	Interrupt the programme and rearrange the items which are obstructing the spray arm
	<i>Rattling noise in the wash cabinet</i>	Item of crockery are insecure in the wash cabinet	Interrupt the programme and rearrange the items of crockery
	<i>Knocking noise in the water pipes</i>	This may be caused by on-site installation or the cross-section of the piping	This has no influence on dishwasher function if in doubt contact a suitably qualified plumber



Poor Washing Result

<i>Problem</i>	<i>Possible Causes</i>	<i>What To Do</i>
<i>The dishes are not clean</i>	The dishes were not loaded correctly	See notes in " Loading the Dishwasher Baskets "
	The program was not powerful enough	Select a more intensive programme See " Wash Cycle Table "
	Not enough detergent was dispensed	Use more detergent or change your detergent
	Item are blocking the path of spray arms	Rearrange the items so that the spray can rotate freely
	The filter combination in the base of wash cabinet is not clean or is not correctly fitted This may cause the spray arm jets to get blocked	Clean and/or fit the filter combination correctly Clean the spray arm jets See "Cleaning the Spray Arms"
<i>Cloudiness on glassware</i>	Combination of soft water and too much detergent	Use less detergent if you have soft water and select a shortest cycle to wash the glassware and to get them clean
<i>Black or gray marks on dishes</i>	Aluminum utensils have rubbed against dishes	Use a mild abrasive cleaner to eliminate those marks
<i>Detergent left in dispenser cups</i>	Dishes block detergent cups	Re-loading the dishes properly

Poor Drying Result

<i>The dishes are not drying</i>	Improper loading	Load the dishwasher as suggested in the directions
	Too little rinse-aid	Increase the amount of rinse-aid/Refill the rinse-aid dispenser
	Dishes are removed too soon	Do not empty your dishwasher immediately after washing. Open the door slightly so that the steam can escape. Begin unloading the dishwasher only once the dishes are barely warm to the touch. Empty the low basket first. This prevents water from dropping off dishes in the upper basket.
	Wrong program selection	In short program the washing temperature is lower. This also lowers cleaning performance. Choose a program with a long washing time.
	Using cutlery with a low-quality coating	Water drainage is more difficult with these items. Cutlery or dishes of this type are not suitable for washing in the dishwasher.

Error Codes


When some malfunctions come on the appliance will display error codes to warn you:

<i>Codes</i>	<i>Meanings</i>	<i>Possible Causes</i>
<i>E1</i>	Longer inlet time	Faucets is not opened or water intake is restricted or water pressure is too low
<i>E3</i>	Not reaching required temperature	Malfunction of heating element
<i>E</i>	Overflow	Some element of dishwasher leaks
<i>Ed</i>	Failure of communication between main PCB with TFT PCB	Open circuit or break of wiring for the communication

⚠ WARNING!

If overflow occurs turn off the main water supply before calling a service
If there is water in the base pan because of an overfill or small leak the water should be removed before restarting the dishwasher

Technical Information



Height :	$17 \frac{1}{4}''$ (38mm)
Width :	$21 \frac{5}{8}''$ (550mm)
Depth :	$19 \frac{11}{16}''$ (500mm)
Voltage connected Load :	see rating label
Water pressure:	0 0 -1 0MPa
Hot water connection :	should be 120 °F
Capacity:	6 place settings

9 1 YEAR LIMITED WARRANTY

This is the only express warranty for this product and is in lieu of any other warranty or condition.

This product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of original purchase. During this period, your exclusive remedy is repair or replacement of this product or any component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us and our returning the product or component under this warranty to you. If the product or component is no longer available, we will replace with a similar one of equal or greater value.

This warranty does not cover wear from normal use or operation that does not comply with the instruction manual or damages to the product resulting from accident, alteration, abuse, or misuse. This warranty extends only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a warranty claim. This warranty is void if product is used for other than single-family household use or subjected to any voltage and waveform other than as specified on the label.

We exclude all claims for special, incidental, and consequential damages by breach of express or implied warranty. All liability is limited to amount of the purchase price. Every implied warranty, including any statutory warranty or condition of merchantability or fitness for particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty or condition is limited to the duration of this written warranty.

This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, incidental consequential damages, so the foregoing limitations may not apply to you.

Customer Service Phone : 1-866-646-4332