


JUICER

Comfee



Instruction Manual

Model: MJ-WJS2005PW



Please read the manual before operating your kettle. Retain it for future reference.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. To protect against risk of electrical shock, do not put cord, plug, base, or motor in water or other liquid.
3. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are closely supervised and instructed concerning use of the appliance by a person responsible for their safety. Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with the appliance.
4. Unplug cord from outlet when not in use, before putting on or taking off parts, and before cleaning. To unplug, grasp the plug and pull from the outlet. Never pull from the power cord.
5. Avoid any contact with blades or moveable parts.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or is dropped or damaged in any manner. Call our toll-free customer service number for information on examination, repair, or electrical or mechanical adjustment.
7. The use of attachments, including canning jars, not recommended or sold by the appliance manufacturer may cause a risk of injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter or touch hot surfaces, including stove.
10. This appliance is intended for household use only. Use for food or liquids only.
11. Always make sure juicer cover is clamped securely in place before motor is turned on. Do not unfasten clamps while juicer is in operation.
12. Be sure to turn switch to OFF position after each use of your juicer. Make sure the motor stops completely before disassembling.

IMPORTANT SAFEGUARDS


13. Do not put your fingers or other objects into the juicer opening while it is in operation. If food becomes lodged in opening, use food pusher or another piece of fruit or vegetable to push it down. When this method is not possible turn the motor off and disassemble juicer to remove the remaining food.
14. Do not use the appliance if the rotating sieve is damaged.
15. Do not operate without the pulp container in place.
16. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
17. A. A short power supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
B. Extension cords are available and may be used if care is exercised in their use.
C. If an extension cord is used
 - (1) the marked electrical rating of the extension cord should be at least as great as electrical rating of the appliance
 - (2) the longer cord should be arranged so that it will not drape over the counter or table top where it could be pulled on by children or tripped over unintentionally.

**SAVE THESE INSTRUCTIONS
HOUSEHOLD USE ONLY**

Product technical parameters

Product name	Model	Voltage	Frequency	Power	Capacity
Juicer	MJ-WJS2005PW	120V~	60Hz	Max.200W	1.0L

Parts name and accessories



Note: The above picture is only for reference since the appearance of the product has lightly difference, please see the real product in the package.

Cautions Before Use


1. Please do not operate the product continuously. If it exceeds 20 minutes, please stop and cool for 20 minutes before continuing juicing to prevent damage to the product.
2. For ingredients with high fibre content (celery, etc.), please cut into pieces around 5 to 10 cm long and 1.5 to 2.5 cm width before putting into the machine. (For fibre rich ingredients, it is best to cut into pieces no more than 3 cm long, then slowly put into the machine.)
3. Extremely hard ingredients such as cereals, sugar cane and ginger are not suitable for juicing.
4. For hard seed ingredients such as cherries, grapefruit, etc., please make sure to deseed; For lemon, orange and other fruits, it is best to be peeled and deseeded, so as it will not affect the fruit juice taste.
5. When processing harder fruits and vegetables, the machine will experience "squeaky" fricative sounds, and the product may experience slight shaking. This situation is normal and please uses it with confidence.
6. Please use fresh fruits and vegetables for juicing, for fruits and vegetables stored in the refrigerator, soak in water for more than 10 minutes before processing, the effect will be better.
7. When processing fruits and vegetables with deeper pigments, such as carrots, beetroots, etc., there will be mild staining of the juice cups and other parts, which is a normal situation.
8. Before starting the machine, please confirm that the juice cup lid is installed in place.
9. When putting in ingredients, it should be put in slowly one by one; the ingredients must be processed before putting in the next ingredients.

Assembly Method


1. How to assemble the seasoning valve at the bottom of the juicing cup.

Push the seasoning valve at the bottom of the juicing cup into the "Hard fruits" position in the direction shown.

Note: The seasoning valve must be installed in place; otherwise there will be leakage problems.




Seasoning valve




Complete installation in position

2. Install the juice cup onto the main unit.


Align the juicing cup to the fixed point on the main unit and push down, and rotate the juicing cup lightly until it is installed in place.



3. Install the filter into the juicing cup.




4. Install the drive shaft into the middle of the filter and press down until it stops.



5. Install the juice cup lid.


Align “♣” on the juice cup lid with “▲” on the juicing cup, turn the juice cup lid clockwise so that the juice cup cover “♣” could align with “▲” on the juicing cup.



6. As shown in the figure, place the juice cup.

Note:

The product is not equipped with a slag cup. It is recommended to use a fruit plate and tableware as slag container.



Functional Description

Forward: For squeezing fresh juice and making ice cream.

Off: Stop the machine after the juicing process is completed.

Reverse: Lifts the fruits and vegetables upwards, solve the stuck issue when juicing; the stuck issue occurs during the process of juicing or making ice cream; the machine reverses to protect the machine from overloading of ingredients or hardened ingredients, and corrects the juice extraction process.


The respective fruits correspond to seasoning valve:

Soft fruits: soft fruit: orange, watermelon, red grape, pineapple, cucumber, tomato, ice cream


Hard fruits: hard fruit + fibre rich Ingredients: apple, pear, celery, carrot, pomegranate

Warning

1. Please do not press the button with wet hands. It is prohibited to idling products for a long period of time before putting in fruits and vegetables.
2. Please do not adjust the seasoning valve frequently during the juicing process.



Hard fruits



Soft fruits

Usage


1. Put the washed large pieces of fruits and vegetables into the feeding chute, turn the knob to pour the fruits and vegetables into the feeding chute, and put the small pieces of fruit and vegetables from the small feeding chute. After putting the material, push the material with a pushing rod.

Note:

Please use fresh fruits and vegetables for juicing, for fruits and vegetables stored in the refrigerator, soak in water for more than 10 minutes before processing, the effect will be better.

Warning

- ① This product is not suitable for crushing cereals, sugarcane and other hard fruits.
- ② For fruits with hard cores, remove cores before juicing.
- ③ For celery and other coarse fiber fruit, washing after juicing 0.5Kg.



2. When the machine suddenly stops during operation, first press the button to the "Stop" position, then press to the "Reverse" position, so that the ingredients held in the drive shaft would be pushed up, and then presses the button to the "forward" position. (Repeat three times or so).


Warning

- ① When the machine is in the "Reverse" mode, please hold the juice cup lid gently with your hand (to prevent the juice cup lid getting loose).
- ② After the above operation, if it still does not operate, please remove the juice cup and wash completely.


3. You may keep the juice outlet lid closed during juicing. When the juice output reaches a certain quantity, open the lid and receive the juice with the juice collector.

Benefits:

- ① Reduce the exposure to air and slow down the oxidation process.
- ② A variety of fruits and vegetables can be used to extract the mixed fruit juice.



Juice outlet is closed




Juice outlet is open

4. After the juicing process, press the button to the "Stop" position and unplug the power cord.

Recommendations:

Please do not store the squeezed juice for long time.




Disassembly Method

1. Press the button to stop the machine and unplug the power cord.


Recommendations:

After the juicing process, press the button to the "Reverse" position and hold for few seconds for easy disassembly and cleaning.


2. Grasp the juice cup lid by hand, and rotate the juice cup cover counter-clockwise as shown in Fig. ①, rotate to the position shown in Fig. ② and pull up the juice cup lid to disassemble.




3. Grab the juice outlet on the juicing cup and lift it upwards to disassemble (see Figure ③).



4. Take out the drive shaft and filter assembly (as shown in Fig. ④).



5. Disassemble the drive shaft and filter separately (as shown in Fig. ⑤).



Ice cream making method

Please put fruits such as bananas (peeled), durian (deseeded), and strawberries (capped) in the freezer for more than 8 hours. Place the special ice cream filter into the juicer. Thaw the frozen fruits for 15 minutes before making, start the machine, and slowly put the fruits into the juicer to make authentic fruit-flavoured ice cream.

Operating steps

1. Put the juice cup on the slag outlet and pick up the ice cream;
2. Push the seasoning valve to "Soft fruits";
3. Press the button to "Forward";
4. Ice cream will be discharged from the slag outlet.

Tips

When making fruit ice cream, you may add frozen milk according to personal taste (the frozen ingredient needs to be thawed at room temperature until the surface slightly softens (more than 20 minutes of thawing in winter and more than 15 minutes in summer), and slowly mix it into the juicer machine to make a delicious ice cream.

Winter: Thawing time is more than 20 minutes; Summer: Thawing time is more than 15 minutes. Put the frozen ingredients slowly into the feeding chute, the feeding interval has to be more than 5 seconds.

Mango and Banana Ice cream

- ① Cut the mango meat and banana into small cubes, and freeze for 8-12 hours in freezer.
- ② Remove from freezer and thaw the frozen fruits for few minutes under room temperature to relieve the hardness;
- ③ Place the special ice cream filter into the juicer, start the machine, put the frozen mango and banana pieces in the feeding chute.
- ④ The ice cream could be consumed directly.

Reminder: the banana ice cream should be consumed as soon as possible.

Dragon fruit ice cream (May add in yoghurt or milk according to personal taste)

- ① Peel the dragon fruit, cut into small cubes, and freeze for 8-12 hours in freezer.
- ② Remove from freezer and thaw the frozen fruits for few minutes under room temperature to relieve the hardness;
- ③ Place the special ice cream filter into the juicer, start the machine, put the frozen dragon fruit pieces in the feeding chute.
- ④ Use a push rod to gently press the fruit cubes, place the ice cream container under the slag outlet, the dragon fruit ice cream is ready;
- ⑤ Remove the filling from the biscuits, place it in a zip lock bag and close it tightly, break the biscuits and serve with the ice cream.

Reminder: the dragon fruit ice cream should be consumed as soon as possible.

Peach ice cream

- ① Wash and peel the peach, take the peach meat cut into small cubes, and freeze for 8-12 hours in freezer.
- ② Put fresh milk into refrigerator;
- ③ Remove the prepared peach from freezer and thaw for few minutes under room temperature to relieve the hardness;
- ④ Put the frozen peach cubes in the feeding chute, add fresh milk according to personal taste;
- ⑤ Use a push rod to gently press the fruit cubes, place the ice cream container under the slag outlet, the peach ice cream is ready;
- ⑥ Add in the favourite jam to make peach fresh milk ice cream.


Reminder: the peach ice cream should be consumed as soon as possible.

Care and Cleaning

Cleaning


1. Wash each disassembled part with running water. If residues plug the filter mesh, please wash the filter with a cleaning brush.

Note: please do not wash by using iron brush and sharp washing tool.




Special reminder:

When washing, push the seasoning valve back and forth for easier cleaning.



2. Do not immerse the main unit into water, only use damp soft cloth to wipe clean.



3. After cleaning, dry the washed parts and store them in a clean and well-ventilated place.

Note:

- ① As the dried slag may affect the disassembly and cleaning, and it may also cause deterioration of performance. Therefore, it should be washed in time after each use.
- ② The rubber gasket below the juice cup is removable and washable.

Maintenance

- 1. This product shall be used frequently to keep the motor dry.
- 2. For prolonged storage, keep it in a dry and ventilated place to prevent the motor from moisture and affecting normal usage.

Any other servicing should be performed by an authorized service representative.

Specifications

Product : JUICER

Model : MJ-WJS2005PW

Rated voltage : 120V~

Rated frequency : 60Hz

Power : Max.200W